

Installation Instructions for set # 43-3002

Installation Instructions Hutch equalizer bushing (2 bolt style)

1. Clean the opening in the arm where the bushing fits. Do Not grease the outside of the bushing or the inside of the arm.
2. Align the two holes in the bushing before pressing in the bushing. Press in the bushing.
3. Grease the O.D. and I.D. of the sleeves. Press in the sleeves. Greasing the I.D. of the sleeve and the O.D. of the bolt will help installation and reduce corrosion.
4. Make sure to center the bushing in the arm so that there is an equal amount protruding from each side of the arm.
5. Do Not grease the faces of the bushing at all. Install the arm on the vehicle.

Inst.#17165
8/2/96
Updated 15/FEB/02 BRH

Supplied sleeves
Grease the O.D. and
the I.D.

